

Hyskore® **Back Pack Shooting Bench** 30009



This Product was designed to be rugged and at the same time compact and portable. We have included an adjustable elbow rest, adjustable cushion seat, and most significantly a fully adjustable spotting scope stand.

In addition the gun support has both a V-Notch and a Pedestal that offer a wide range of gun mounting options.


There are a few Important Cautions that you should pay attention to:

(A) The various assemblies and components of this bench are designed to stay solidly in place **when properly deployed and secured**. Failure to do this could result in damage to your weapon and / or personal injury.

(B) This bench has numerous parts that fold, hinge, etc. thereby presenting numerous opportunities for pinching your fingers. It is suggested that you pay close attention during the set up and take down procedures to avoid crushing parts of your body.

(C) The gun rest arm is hinged to facilitate vertical rotation of the gun. This being said, you should always maintain personal "hands on" control of your gun to avoid damage or injury that could result from an unattended weapon pitching forward or backward and falling off the rest.

STEP 1




Pry out the legs and extend them to their full width. **Important!** The leg sets must be set to their full forward and rear positions and to their side to side stops. If you fail to follow this step, the legs could fold while the bench is in use.

STEP 2



Fit the rubber feet to the ends of the legs.

STEP 3




Fit the seat to the frame. It can be adjusted up to 8" front to back.

STEP 4




Mount the mast arm bracket as shown. Make it snug (4 -5 Lbs. / FT of torque), not to tight as it must pivot.

STEP 5




Fit bolt "A" to the frame and tighten to 12 - 15 Lbs. of torque. Place the spring and washer over it as shown.

STEP 6



Place the retaining clamp over the bolt as shown. (Flanges facing down) Tighten the wing nut 1.5 - 2 turns.

STEP 7




Rotate the hinge forward as shown. Rotate the clamp 90° and hand tighten the wing nut. Note how the flanges fit.

STEP 8



Insert the mast.
(Do Not tighten at this time.)

STEP 9 - Assemble the Elbow Rest



NOTE: This view is from the underside.
Assemble the elbow rest to the clamp.
Tighten to 4 - 5 Lbs. of torque as the
arm must pivot.

STEP 10



Remove the mast. Slide it through the elbow rest
and clamp as shown. Return the mast to the mast
bracket.

STEP 11



Install the gun rest assembly as shown. You
can choose from a wide range of set - ups.

STEP 12



How things should look before setting up the
spotting scope stand.

STEP 13



Install the spotting scope stand as shown. It can mount either left or right.


STEP 14




Most modern spotting scopes are tapped 1/4" x #20. Using the 1/4" x # 20 shoulder bolt and the special knob, mount your scope as shown.

Note: If the hole in the scope is not deep enough you will need to place 1 or 2 1/4" flat washers between the shoulder of the bolt and the scope mount bracket.

Exploded View




STEP 15 - Take Down (A)



1. Extend the mast so that the lower end is flush with the bottom of mast arm bracket. Secure with knob "M"
2. Loosen Knob "D" rotate the gun support 90° rearward and secure with knob "D".
3. Remove the spotting scope support
4. Fold the legs. (Reverse of STEP 1)


STEP 16 - Take Down (B)




1. Make sure the retaining clamp is in the storage position (STEP 4). Hand tighten the wing nut.
2. Rotate the mast approximately 90°
3. Retract the elbow rest to it's shortest position and move the seat to its rear most point.
4. Use the straps to secure the rest.

REPLACEMENT PARTS


30009 - 1




30009 - 2




30009 - 3




30009 - 4




30009 - 5




30009 - 6




30009 - 7




30009 - 8




30009 - 9




30009 - 10



30009 - 11



30009 - 12



• PRICE LIST •

30009 - 1	Base & Leg Assembly	\$ 35.00
30009 - 2	Mast Assembly	\$ 22.50
30009 - 3	Spotting Scope Stand Assembly	\$ 25.50
30009 - 4	Arm Rest Assembly	\$ 22.50
30009 - 5	Seat & Nut Set	\$ 22.50
30009 - 6	Gun Rest Support Arm	\$ 19.50
30009 - 7	Pedestal & "V" Notch Gun Rest Set	\$ 25.50
30009 - 8	Mast Arm Bracket	\$ 27.50
30009 - 9	Arm Rest & Scope Stand Clamp Assembly	\$ 27.50
30009 - 10	Feet - 4 Pc. Set	\$ 9.50
30009 - 11	Locking Nut Set - 4 Pcs.	\$ 9.50
30009 - 12	Scope Mount Nut, Shoulder Bolt & Bracket	\$ 12.50

Visit Our Website For More Information or to
Check Out Our Other Great Shooting Accessories:
www.hyskore.com

Send Check or Money Order
with Phone Number to:

Power Aisle, Inc.

P.O. Box 983

Middleburgh, NY 12122

NYS Resident add appropriate Sales Tax

**** \$10.00 Shipping & Handling to
Lower 48 States****

**** \$25.00 Shipping & Handling to
Alaska, Hawaii, Puerto Rico****

LIMITED LIABILITY and WARRANTY

POWER AISLE, INC. / HYSKORE GUARANTEES THAT ITS PRODUCTS ARE FREE FROM DEFECT IN MATERIAL & WORKMANSHIP. IN THE EVENT OF ANY DEFECTS IN MATERIAL OR WORKMANSHIP, POWER AISLE, INC. / HYSKORE'S SOLE LIABILITY THEREFORE SHALL BE THE REPLACEMENT OF ANY SUCH PRODUCT(S) THAT ARE DEFECTIVE IN MATERIAL OR WORKMANSHIP. THE REPLACEMENT OF ANY SUCH PRODUCT(S) SHALL BE POWER AISLE, INC. / HYSKORE'S SOLE RESPONSIBILITY. THIS WARRANTY SPECIFICALLY EXCLUDES ANY & ALL CONSEQUENTIAL OR ACCIDENTAL DAMAGES. NO OTHER WARRANTIES OR LIABILITY WHATSOEVER, ARE EITHER EXPRESSED OR IMPLIED. IF ANY SUCH WARRANTIES SHALL BE IMPOSED BY LAW NOTWITHSTANDING THIS PROVISION, THEN SUCH WARRANTIES SHALL BE THE RESPONSIBILITY OF POWER AISLE, INC. / HYSKORE'S IMMEDIATE BUYER. THERE SHALL BE NO WARRANTIES OF MERCHANTABILITY, USE OF TRADE, OR FITNESS FOR A PARTICULAR PURPOSE. ALTERING THIS PRODUCT, MISUSING IT OR EXCEEDING ANY STATED PRODUCT LIMITATIONS VOIDS THIS WARRANTY.